

AIRPLANE FLYING HANDBOOK

Revised 1999

**U.S. DEPARTMENT OF TRANSPORTATION
FEDERAL AVIATION ADMINISTRATION**
Flight Standards Service

Ex. B - 40

CONTENTS

CHAPTER 1—INTRODUCTION TO FLIGHT TRAINING

INTRODUCTION	1-1
CHOOSING A FLIGHT SCHOOL	1-1
INSTRUCTOR/STUDENT RELATIONSHIP	1-1
ROLE OF THE FAA	1-1
FLIGHT STANDARDS DISTRICT OFFICES (FSDO's)	1-3
STUDY HABITS	1-3
STUDY MATERIALS	1-3
COLLISION AVOIDANCE	1-4

CHAPTER 2—PREFLIGHT, POSTFLIGHT, AND GROUND OPERATIONS

INTRODUCTION	2-1
PILOT ASSESSMENT	2-1
PREFLIGHT PREPARATION AND FLIGHT PLANNING	2-1
AIRPLANE PREFLIGHT INSPECTION	2-2
MINIMUM EQUIPMENT LISTS (MEL's) AND OPERATIONS WITH INOPERATIVE EQUIPMENT	2-4
COCKPIT MANAGEMENT	2-5
USE OF CHECKLISTS	2-5
GROUND OPERATIONS	2-6
TAXIING	2-8
TAXI CLEARANCES AT AIRPORTS WITH AN OPERATING CONTROL TOWER	2-10
BEFORE TAKEOFF CHECK	2-10
AFTER-LANDING	2-11
POSTFLIGHT	2-12

CHAPTER 3—TAKEOFFS AND CLIMBS

INTRODUCTION	3-1
TERMS AND DEFINITIONS	3-1
PRIOR TO TAKEOFF	3-2
NORMAL TAKEOFF	3-2
CROSSWIND TAKEOFF	3-4
SHORT-FIELD TAKEOFF AND CLIMB	3-6
SOFT-FIELD TAKEOFF AND CLIMB	3-7
REJECTED TAKEOFF	3-10
NOISE ABATEMENT	3-10

CHAPTER 4—BASIC FLIGHT MANEUVERS

INTRODUCTION	4-1
INTEGRATED FLIGHT INSTRUCTION	4-1
ATTITUDE FLYING	4-1
STRAIGHT-AND-LEVEL FLIGHT	4-2
TURNS	4-2
CLIMBS	4-7
DESCENTS	4-9

CHAPTER 5—SLOW FLIGHT, STALLS, AND SPINS

INTRODUCTION	5-
SLOW FLIGHT	5-
STALLS	5-1
SPINS	5-1
SPIN PROCEDURES	5-1
AIRCRAFT LIMITATIONS	5-1
WEIGHT AND BALANCE REQUIREMENTS	5-1

CHAPTER 6—GROUND REFERENCE AND PERFORMANCE MANEUVERS

INTRODUCTION	6-
MANEUVERING BY REFERENCE TO GROUND OBJECTS	6-
PERFORMANCE MANEUVERS	6-1

CHAPTER 7—AIRPORT TRAFFIC PATTERNS, APPROACHES, AND LANDINGS

INTRODUCTION	7-
AIRPORT TRAFFIC PATTERNS AND OPERATIONS	7-
NORMAL APPROACH AND LANDING	7-
CROSSWIND APPROACH AND LANDING	7-1
SHORT-FIELD APPROACH AND LANDING	7-1
SOFT-FIELD APPROACH AND LANDING	7-1
POWER-OFF ACCURACY APPROACHES	7-1

CHAPTER 8—FAULTY APPROACHES AND LANDINGS

INTRODUCTION	8-
FINAL APPROACHES	8-
ROUNDOUT (FLARE)	8-
TOUCHDOWN	8-

CHAPTER 9—FLIGHT BY REFERENCE TO INSTRUMENTS

INTRODUCTION	9-1
BASIC INSTRUMENT TRAINING	9-1
BASIC INSTRUMENT FLIGHT	9-2
USE OF NAVIGATION SYSTEMS	9-8
USE OF RADAR SERVICES	9-9

CHAPTER 10—NIGHT OPERATIONS

INTRODUCTION	10-1
NIGHT VISION	10-1
NIGHT ILLUSIONS	10-2
PILOT EQUIPMENT	10-3
AIRPLANE EQUIPMENT AND LIGHTING	10-3

AIRPORT AND NAVIGATION LIGHTING AIDS	10-4
PREPARATION AND PREFLIGHT	10-5
STARTING, TAXIING, AND RUNUP	10-5
TAKEOFF AND CLIMB	10-6
ORIENTATION AND NAVIGATION	10-7
APPROACHES AND LANDINGS	10-7
NIGHT EMERGENCIES	10-8

CHAPTER 11—NAVIGATION SYSTEMS

INTRODUCTION	11-1
VOR NAVIGATION	11-1
VOR/DME RNAV	11-4
LORAN-C NAVIGATION	11-5
GLOBAL POSITIONING SYSTEM (GPS)	11-6
RADAR SERVICES	11-8

CHAPTER 12—EMERGENCY OPERATIONS

INTRODUCTION	12-1
SYSTEMS AND EQUIPMENT MALFUNCTIONS	12-1
EMERGENCY APPROACHES AND LANDINGS (ACTUAL)	12-3

CHAPTER 13—TRANSITION TO DIFFERENT AIRPLANES AND SYSTEMS

INTRODUCTION	13-1
GENERAL	13-1
TRANSITION TO DIFFERENT MAKE AND/OR MODEL AIRPLANES	13-1
AIRPLANE SYSTEMS	13-2
PRESSURIZED AIRPLANES	13-3
OXYGEN SYSTEMS	13-5
PHYSIOLOGICAL ALTITUDE LIMITS	13-7
REGULATORY REQUIREMENTS	13-7

CHAPTER 14—TRANSITION TO A MULTIENGINE AIRPLANE

INTRODUCTION	14-1
MULTIENGINE PERFORMANCE CHARACTERISTICS	14-1
THE CRITICAL ENGINE	14-2
VMC FOR CERTIFICATION	14-3
PERFORMANCE	14-5
FACTORS IN TAKEOFF PLANNING	14-5
ACCELERATE/STOP DISTANCE	14-7
PROPELLER FEATHERING	14-9
USE OF TRIM TABS	14-10
PREFLIGHT PREPARATION	14-10
CHECKLIST	14-10
TAXIING	14-11
NORMAL TAKEOFFS	14-11
CROSSWIND TAKEOFFS	14-12

SHORT-FIELD OR OBSTACLE CLEARANCE TAKEOFF ..	14-12
STALLS	14-13
EMERGENCY DESCENT	14-13
APPROACHES AND LANDINGS	14-14
CROSSWIND LANDINGS	14-15
SHORT-FIELD LANDING	14-15
GO-AROUND PROCEDURE	14-15
ENGINE INOPERATIVE EMERGENCIES	14-16
ENGINE INOPERATIVE PROCEDURES	14-16
VMC DEMONSTRATIONS	14-17
ENGINE FAILURE BEFORE LIFT-OFF (REJECTED TAKEOFF)	14-17
ENGINE FAILURE AFTER LIFT-OFF	14-17
ENGINE FAILURE EN ROUTE	14-19
ENGINE INOPERATIVE APPROACH AND LANDING	14-20

CHAPTER 15—TRANSITION TO TAILWHEEL AIRPLANES

INTRODUCTION	15-1
LANDING GEAR	15-1
TAXIING	15-1
NORMAL TAKEOFF ROLL	15-2
TAKEOFF	15-3
CROSSWIND TAKEOFF	15-3
SHORT-FIELD TAKEOFF	15-4
SOFT-FIELD TAKEOFF	15-4
TOUCHDOWN	15-4
AFTER-LANDING ROLL	15-5
CROSSWIND LANDING	15-5
CROSSWIND AFTER-LANDING ROLL	15-6
WHEEL LANDING	15-6
SHORT-FIELD LANDING	15-6
SOFT-FIELD LANDING	15-7
GROUND LOOP	15-7

CHAPTER 16—TRANSITION TO SEAPLANES

INTRODUCTION	16-1
TERMS AND DEFINITIONS	16-1
GENERAL	16-2
CHARACTERISTICS OF WATER	16-2
CHARACTERISTICS OF SEAPLANES	16-4
SEAPLANE BASES/LANDING AREAS	16-5
SAFETY RULES FOR SEAPLANES	16-5
PREFLIGHT INSPECTION	16-6
TAXIING	16-6
BEFORE TAKEOFF	16-10
TAKEOFFS	16-10
LANDINGS	16-13
ANCHORING, MOORING, DOCKING, AND BEACHING	16-17

**CHAPTER 17—TRANSITION TO
SKIPLANES**

INTRODUCTION	17-1
TERMS AND DEFINITIONS	17-1
GENERAL	17-2
GROUND OPERATIONS	17-3
OFF AIRPORT LANDING SITES	17-5
EMERGENCY OPERATIONS	17-6

CHAPTER 18—AERONAUTICAL DECISION MAKING

INTRODUCTION	18-1
GENERAL	18-1
TYPES OF DECISIONS	18-1
EFFECTIVENESS OF ADM	18-2

INDEX	I-1
-------------	-----

After-Landing Roll

The landing process must never be considered complete until the airplane decelerates to the normal taxi speed during the landing roll or has been brought to a complete stop when clear of the landing area. Many accidents have occurred as a result of pilots abandoning their vigilance and positive control after getting the airplane on the ground.

The pilot must be alert for directional control difficulties immediately upon and after touchdown due to the ground friction on the wheels. The friction creates a pivot point on which a moment arm can act.

Loss of directional control may lead to an aggravated, uncontrolled, tight turn on the ground, or a ground loop. The combination of centrifugal force acting on the center of gravity (CG) and ground friction of the main wheels resisting it during the ground loop may cause the airplane to tip or lean enough for the outside wingtip to contact the ground. This may even impose a sideward force which could collapse the landing gear.

The rudder serves the same purpose on the ground as it does in the air—it controls the yawing of the airplane. The effectiveness of the rudder is dependent on the airflow, which depends on the speed of the airplane. As the speed decreases and the nosewheel has been lowered to the ground, the steerable nose provides more positive directional control.

The brakes of an airplane serve the same primary purpose as the brakes of an automobile—to reduce speed on the ground. In airplanes they may also be used as an aid in directional control when more positive control is required than could be obtained with rudder or nosewheel steering alone.

To use brakes, on an airplane equipped with toe brakes, the pilot should slide the toes or feet up from the rudder pedals to the brake pedals. If rudder pressure is being held at the time braking action is needed, that pressure should not be released as the feet or toes are being slid up to the brake pedals, because control may be lost before brakes can be applied.

During the ground roll, the airplane's direction of movement can be changed by carefully applying pressure on one brake or uneven pressures on each brake in the desired direction. Caution must be exercised when applying brakes to avoid overcontrolling.

The ailerons serve the same purpose on the ground as they do in the air—they change the lift and drag components of the wings. During the after-landing roll, they should be used to keep the wings level in much

the same way they were used in flight. If a wing starts to rise, aileron control should be applied toward that wing to lower it. The amount required will depend on speed because as the forward speed of the airplane decreases, the ailerons will become less effective. Procedures for using ailerons in crosswind conditions are explained further in this chapter, in the crosswind landings section.

After the airplane is on the ground, back-elevator pressure may be gradually relaxed to place normal weight on the nosewheel to aid in better steering.

If available runway permits, the speed of the airplane should be allowed to dissipate in a normal manner. Once the airplane has slowed sufficiently and has turned on to the taxiway and stopped, the pilot should retract the flaps and clean up the airplane. Too many accidents have occurred as a result of the pilot unintentionally operating the landing gear control and retracting the gear instead of the flap control when the airplane was still rolling. The habit of positively identifying both of these controls, before actuating them, should be formed from the very beginning of flight training and continued in all future flying activities.

Hydroplaning

When there is a film of water on a runway, the airplane ground controllability and braking efficiency can be seriously affected. As the speed of the airplane and depth of the water increase, the water layer builds up an increasing resistance to displacement, resulting in the formation of a wedge of water beneath the tire. This progressively lifts the tire, decreasing the area in contact with the runway and causes the airplane to hydroplane on the film of water. In this condition, the tires no longer contribute to directional control and braking action is nil.

There are basically three types of hydroplaning they are dynamic, viscous, and reverted rubber.

Dynamic

Dynamic hydroplaning occurs when there is standing water on the runway surface. Water about one-tenth of an inch deep acts to lift the tire off the runway as explained above.

Viscous

Viscous hydroplaning is due to the viscous properties of water. A thin film of fluid no more than one-thousandth of an inch in depth cannot be penetrated by the tire and the tire rolls on top of this film. This can occur at a much lower speed than dynamic

AFTER-LANDING ROLL

The landing process must never be considered complete until the airplane decelerates to the normal taxi speed during the landing roll or has been brought to a complete stop when clear of the landing area. The pilot must be alert for directional control difficulties immediately upon and after touchdown due to the ground friction on the wheels. The friction creates a pivot point on which a moment arm can act. This is because the CG is behind the main wheels. [Figure 15-2]




FIGURE 15-2—Effect of CG on directional control.

Any difference between the direction the airplane is traveling and the direction it is headed will produce a moment about the pivot point of the wheels, and the airplane will tend to swerve. Loss of directional control may lead to an aggravated, uncontrolled, tight turn on the ground, or a ground loop. The combination of inertia acting on the CG and ground friction of the main wheels resisting it during the ground loop may cause the airplane to tip or lean enough for the outside wingtip to contact the ground, and may even impose a sideward force that could collapse the landing gear. The aircraft can ground loop late in the after-landing roll because rudder effectiveness decreases with the decreasing flow of air along the rudder surface as the airplane slows. As the airplane speed decreases and the tailwheel has been lowered to the ground, the steerable tailwheel provides more positive directional control.

To use the brakes, the pilot should slide the toes or feet up from the rudder pedals to the brake pedals. If rudder pressure is being held at the time braking action is needed, that pressure should not be released as the feet or toes are being slid up to the brake pedals, because control may be lost before brakes can be applied. During the ground roll, the airplane's direction of movement may be changed by carefully applying pressure on one brake or uneven pressures on each brake in the desired direction. Caution must be exercised, when applying brakes to avoid overcontrolling.

If a wing starts to rise, aileron control should be applied toward that wing to lower it. The amount required will depend on speed because as the forward speed of the airplane decreases, the ailerons will become less effective.

The elevator control should be held back as far as possible and as firmly as possible, until the airplane stops. This provides more positive control with tailwheel steering, tends to shorten the after-landing roll, and prevents bouncing and skipping.

If available runway permits, the speed of the airplane should be allowed to dissipate in a normal manner by the friction and drag of the wheels on the ground. Brakes may be used if needed to help slow the airplane. After the airplane has been slowed sufficiently and has been turned onto a taxiway or clear of the landing area, it should be brought to a complete stop. Only after this is done should the pilot retract the flaps and perform other checklist items.

CROSSWIND LANDING

If the crab method of drift correction has been used throughout the final approach and roundout, the crab must be removed before touchdown by applying rudder to align the airplane's longitudinal axis with its direction of movement. This requires timely and accurate action. Failure to accomplish this results in severe sideloads being imposed on the landing gear and imparts ground looping tendencies.

If the wing-low method is used, the crosswind correction (aileron into the wind and opposite rudder) should be maintained throughout the roundout, and the touchdown made on the upwind main wheel.

During gusty or high-wind conditions, prompt adjustments must be made in the crosswind correction to assure that the airplane does not drift as the airplane touches down.